



## Replacing AstroGuard/AstroFlex Panels

If you need to replace a damaged AstroGuard/AstroFlex Panel, please follow the directions below;

- 1 - Ensure all anchors are clean and free of debris.
- 2 – You may reuse existing Clips if undamaged or purchase new Clips as needed.
- 3 – Install the Clips on each anchor with a hand tightened Philips screwdriver.



4 – If the existing Clips are on each side, mark the new panel at 2” from the top edges. Similarly, if the Clips are top and bottom mark the panel 2” from the left or right edge. This will establish your starting point. The mark will be the center of the Clip



5 – With an assistant, install the Panel on the first top Clip with the two center screws. The remaining six screws can be installed once the panel is completely installed. Be sure the clip is “square” to the panel to avoid



6 – Pull the Panel across the opening to the opposing Clip and secure with two screws. The Panel should be tight.

7 – Proceed down the Panel, keeping it taut and unwrinkled.

8 – Wet the Panel with a garden hose and keep it installed until completely dry.

9 – Remove the Panel and store in a clean, dry environment.

10 – Dab the Sidewalk Bolts with a little White Lithium Grease and install in the anchors. Be sure the washers are in place on the bolts.